

# CKS208 Quick Guide

## TIME SET

Time → Day → Year → 12/24H

### STEP 1



Press **CLOCK SET** for 2 seconds to entry time setting.



Press ▲ or ▼ to adjust the Minute.  
Press ◀ or ▶ to adjust the Hour.

### STEP 2



Press **CLOCK SET** to next, Month / Date segment will blink.



Press ▲ or ▼ to adjust the Date.  
Press ◀ or ▶ to adjust the Month.

### STEP 3



Press **CLOCK SET** to next, Year segment will blink.




Press ◀ or ▶ to adjust the Year.

### STEP 4



Press **CLOCK SET** to next, 12H / 24H segment will blink.



Press ◀ or ▶ to adjust the time format.

### STEP 5

Press **CLOCK SET** again to store the time setting, or wait for 40 seconds.

## ALARM SET

Time → Volume → Alarm working days

1/2 📢 Wake to Buzzer  
1/2 📻 Wake to Radio

### STEP 1



Press and hold the AL1 / AL2 for 2 seconds to entry alarm setting.



Press ◀ or ▶ to adjust the Hour.



Press ▲ or ▼ to adjust the Minute.

## STEP 2



Press **AL1 / AL2** again, the current volume level will blink.

Press **▲** or **▼** to adjust the volume.

## STEP 3



Press **AL1 / AL2** again, the current day mode will blink.

Press **▲** or **▼** to choose alarm working days.



Week



Work day



Weekend



Single day



## STEP 4

Press **AL1 / AL2** again to store the alarm setting, or wait for 40 seconds.

# SNOOZE/ STOP/ TURN OFF THE ALARM



1. **SNOOZE** : Alarm will pause 9 minutes for each press, 6 times at most.



2. **Stop the alarm** : Press **AL1 / AL2** when the alarm is ringing.



3. **Turn off the alarm completely** : Press **AL1 / AL2** repeatedly until all the alarm indicator OFF from the display.