


# CKS708 Quick Guide

## TIME SETTING

Time → Day → Year → 12/24H


### STEP 1



Press **TIME SET** for 2 second to entry time setting.

Press ▲ or ▼ to adjust the Hour.  
Press ◀ or ▶ to adjust the Minute.

### STEP 2



Press **TIME SET** to next, Month / Date segment will blink.

Press ▲ or ▼ to adjust the Month.  
Press ◀ or ▶ to adjust the Date.



### STEP 3



Press **TIME SET** to next, Year segment will blink.

Press ◀ or ▶ to adjust the Year.

### STEP 4



Press **TIME SET** to next, 12H / 24H segment will blink.

Press ◀ or ▶ to adjust the time format.

### STEP 5


Press **TIME SET** again to store the time setting, or wait for 40 seconds.

## ALARM SETTING

Time → Volume → Alarm working days

1/2 📞 Wake to Buzzer  
1/2 📻 Wake to Radio


### STEP 1



Press **AL1 / AL2** for 2 seconds to entry alarm setting. The Hour of wake up time will blink.

Press ▲ or ▼ to adjust the Hour.  
Press ◀ or ▶ to adjust the Minute.

## STEP 2




Press **AL1 / AL2** to next, the current volume level will blink.



Press **▲** or **▼** to adjust the volume.



## STEP 3



Press **AL1 / AL2** to next, the current day mode will blink.



Press **▲** or **▼** to choose alarm working days.




Single day



Work day



Weekend



Week




## STEP 4

Press **AL1 / AL2** again to store the alarm setting, or wait for 40 seconds.



# SNOOZE/ STOP/ TURN OFF THE ALARM



1. **SNOOZE** : Alarm will pause 9 minutes for each press, 6 times at most.



2. **Stop the alarm** : Press **AL1 / AL2** when the alarm is ringing.



3. **Turn off the alarm completely** : Press **AL1 / AL2** repeatedly until all the alarm indicator OFF from the display.